

Installation instruction - Deizign wall absorber

Wall panel with keyhole suspension. The measure submitted to cc on the keyhole is always 90 mm from each edge. Equal in all four corners. Mark out this and then screw in the appropriate screw depending on the wall. Then, install the absorber and ensure that it locks. Important not to screw with the small skull on. This prevents the absorbent slip by.

Wall absorber with keyhole

