

Installation instruction - Dezign wall absorber

Begin to remove the portion of the plastic to sit on the wall.
Then screw it up to the desired height, use our help measure see in the picture to the right.
When the seal is at the desired height, hang up absorbent.

