

Installation instruction - Fazett wall absorber

Start by measuring out where the bottom Fazetten in your pattern will sit. Add a few extra minutes to really get the first at the right place when it makes the rest of the building.

Set, while a plate with Velcro and place where the center of Fazetten should be (see picture at right). Screw the plate with the appropriate screws for that era wall.

Then just press where the absorbent. The relatively large plate makes Fazetten not have to sit exactly in the middle. You can also remove and move them around.

