

ZilenZio

Selling silence

Installation instruction - Timber roof absorber

First attach the supplied wire rope to the ceiling.

Fasteners are not provided by ZilenZio. This is because all the roof are so different.

If they are to be attached to the ceiling so there is a ceiling bracket to mount the roof rail system. Then attach the cable to the bracket.

Supplied rail mounting Timber on. This rail has threaded holes on the upper side where the enclosed wire lock to be screwed there. Once this is done then just threading the cable and set the desired height of the bar.

Installation of the panels, the non-upholstered side must always be upward. Sitting magnets at the top and bottom so start by securing desired Timber on the bar then just continue to catch on to others. Fit to advantage all the upper tiles first and then work your way down. To avoid tipping bar.

Do not place the tiles in dirty environment where they wait to be fitted when the magnets are also at the bottom as happy pulling small magnetic particles.

